



Service Manual

ВНИМАНИЕ!!!Эта схема НЕ предназначена для продажи на дисках.Схему можно свободно получить на сайте


"www.radiolom.by.ru"(www.hot.ee/juden001/).Если Вы её

купили на болванке,то Вас капитально наебли!Не

поддерживайте этих пидоров-торговцев краденным!!!

WARNING!!!This scheme not for selling on CD,its possible liberally get on put www.radiolom.by.ru.If You have sold this scheme on CD,that You have well defrauded.Do Not buy the thieved belongings!The Death thief!

COLOUR TV



MODEL

CT-21A5LST
CT-21A5STX
CT-25A5STX

CAUTION



Before servicing this chassis, it is important that the serviceman reads the "SAFETY PRECAUTIONS" in this service manual.

SPECIFICATION



• Power Input	AC 230V; 50Hz [CT-21A5LST] AC 240V; 50Hz [CT-21/25A5STX]	• Chassis	E14SF
• Power Consumption	88W [CT-21A5LST/STX] 97W [CT-25A5STX]	• Picture tube	A51EAL55X01 21" 90° Deflection [21" model] A59ECY13X01 25" 110° Deflection [25" model] 26.5kV (at 1.0mA)
• Reception System	CCIR-I	• Picture high voltage	
• Colour System	PAL, 60PAL	• Cabinet Dimensions	495(W)×447(H)×485(D)mm [CT-21A5LST/STX] 572(W)×505(H)×442(D)mm [CT-25A5STX]
• Reception	VHF 44.5~60.5MHz, 174~214MHz [CT-21A5LST] UHF 470~870MHz CATV 68~89MHz, 104~470MHz [CT-21A5LST]	• Weight(Approx.)	21.9kg [CT-21A5LST/STX] 26.2kg [CT-25A5STX]
• Intermediate Frequency	Video IF Carrier 39.5MHz Sound IF Carrier 33.5MHz		
• Aerial Input	75Ω		
• Speaker	100mm Round type 2pcs 40mm × 70mm 2pcs		

MITSUBISHI ELECTRIC

CONTROLS AND CABINET PARTS



SCARTS SOCKET CONNECTORS



MODE PIN	AV1	AV2	MODE PIN	AV1	AV2
1	AUDIO OUT R		12	NOT CONNECTED	
2	AUDIO IN R		13	RED EARTH	NOT CONNECTED
3	AUDIO OUT L		14	BLANKING EARTH	NOT CONNECTED
4	AUDIO EARTH		15	RED IN	NOT CONNECTED
5	BLUE EARTH	NOT CONNECTED	16	RGB STATUS (BLANKING)	NOT CONNECTED
6	AUDIO IN L		17	VIDEO EARTH	
7	BLUE IN	NOT CONNECTED	18	VIDEO IN EARTH	
8	FUNCTION SWITCH		19	VIDEO OUT	
9	GREEN EARTH	NOT CONNECTED	20	VIDEO IN	
10	NOT CONNECTED		21	SOCKET EARTH	
11	GREEN IN	NOT CONNECTED			


LEAD DRESS

The lead wires clamped are listed in the table below.

Note: The inner wires are clamped so that they do not come close to the heat generating or high-tension parts. After servicing route all wires in their original position.

The anode lead wires are routed so no tensile strength is applied to the anode cap. If the mounting angle of the anode cap and the route of the anode lead wires are changed. Return them to the initial angle and route.

ВНИМАНИЕ!!!Эта схема НЕ предназначена для продажи на дисках.Схему можно свободно получить на сайте "www.radiolom.by.ru"(www.hot.ee/jude n001/).Если Вы её купили на болванке,то Вас капитально наебли!Не поддерживайте этих пидоров-торговцев краденным!!! WARNING!!!This scheme not for selling on CD,its possible liberally get on put www.radiolom.by.ru.If You have sold this scheme on CD,that You have well defrauded.Do Not buy the thieved belongings!The Death thief!



CLAMPER LIST FOR CONNECTOR LEAD


CONNECTOR LEAD	CLAMP
ANODE-LEAD	⑤ must be held by ①⑨
DD	⑥
DJ-SP393	② - ①⑤ - ⑧ - ⑨ - ⑩ - ①① - ①② - ①③ (21" only) - ①④
DJ-SP394	②
DK	② (Loop DK to take up slack)
DY	③ (1 loop) - ①⑥ - ①⑦
FOCUS-LEAD	④ - ②①
GA	⑥ - ①⑨ - ②②
KB	①
LB	④ - ②①
PC	⑦ (1 loop 21" only) - ①
SA	①⑥ - ①⑦
SCREEN LEAD	④ - ②①

LEAD CONNECTOR COLOUR CODE

Lead connectors show the connector names by colour codes of leads, not printed any connector names. When connecting or removing them, identify connector names according to colour codes in the table below. Colour Codes (See Pin Nos. 1 and 2 of connectors)

Colour	Code
BLACK	A
BROWN	B
RED	C
ORANGE	D
YELLOW	E
GREEN	NOT USED (GROUND)
BLUE	G
VIOLET	H
GREY	J
WHITE	K
PINK	L

Example:



WHEN SERVICING PCB USE THE EXTENSION CORD

PRINTED CIRCUIT BOARD	CONNECTOR	PARTS NO.
AV NICAM TEXT LED/PRE	CB (15pin) DA (9pin), DB (12pin) HB (8pin) HC (5pin)	859C431O40
PCC-CONT (only 25")	LA (6pin)	859C431O60
AV	CA (11pin)	859C432O40
TEXT	HA (10pin)	859C432O80

ELECTRICAL ADJUSTMENT

Perform only the alignments required.
If proper equipment is not available, do not attempt an alignment.

■ Measuring equipment and Jigs

- Oscilloscope (Unless otherwise specified in particular, use 10:1 probes.)
- Signal generator
- Direct current milliammeter
- Direct current voltmeter.
- Electrical tools


■ Test Signal

1) Monoscope signal

When you have no monoscope signal source for adjustment, connect the unit to a VCR and play an alignment tape (Monoscope).

2) Colour bar signal

In this manual, unless otherwise specified in particular, use colour bar signal in specifications below.




PAL

Split-Field Colour Bars (with 100% window)


ВНИМАНИЕ!!!Эта схема НЕ предназначена для продажи на дисках.Схему можно свободно получить на сайте "www.radiolom.by.ru"(www.hot.ee/juden001/).Если Вы её купили на болванке,то Вас капитально наебли!Не поддерживайте этих пидоров-торговцев краденным!!!
WARNING!!!This scheme not for selling on CD,its possible liberally get on put www.radiolom.by.ru.If You have sold this scheme on CD,that You have well defrauded.Do Not buy the thieved belongings!The Death thief!

LOCATION OF TESTPOINTS AND ADJUSTMENTS


PCB-MAIN (COMPONENT SIDE)




PCB-CRT (SOLDER SIDE)



PCB-PCC CONT (COMPONENT SIDE)




PCB-NICAM (COMPONENT SIDE)




[Audio Detection Circuit] 1. VCO Coil		Adjustment purpose Setting VCO free run frequency. Symptom when incorrectly adjusted NICAM and normal audio poor also S/N ratio poor.
---	--	--

Measuring instrument	DC Voltmeter	1. Remove the ANTENNA cable from RF IN terminal. 2. Short-circuit TP3F and ground. 3. Observe the DC voltage at TP3D. 4. Measure the DC voltage on TP3D. 5. Open the short circuit of TP3F and ground. 6. Supply a sinewave signal (39.5MHz, 90±2dBμ) to TP3B using the circuit, as shown in figure. 7. Adjust L3110 so that the voltage reading on TP3D is same value the reading measured in step 4. Note: There are three adjustment points of L3110. After adjustment, make sure that the set movements is normal. If necessary, set L3110 to the other adjustment points so that the set movements is normal.
Test point	TP3D	
EXT trigger	---	
Measurement range	---	
Input signal	Sinewave signal (39.5MHz, 90±2dBμ)	
Input terminal	TP3B	

PCB-NICAM (COMPONENT SIDE)







2. Audio Detection Coil		Adjustment purpose Detect audio signal to optimum. Symptom when incorrectly adjusted Normal audio poor or distorted.
--------------------------------	--	---

Measuring instrument	Oscilloscope	1. Supply an RF signal of normal audio (400Hz, 30% MOD). 2. Observe the waveform at TP3G. 3. Adjust L3111 so that the centre level of the amplitude is DC5V.
Test point	TP3G	
EXT trigger	---	
Measurement range	DIV 50mV TIM 1ms	
Input signal	RF signal (Normal audio)	
Input terminal	RF IN terminal	

PCB-NICAM (COMPONENT SIDE)





[VIF circuit] 3. RF AGC		Adjustment purpose	The best receiving condition of RF signal.
		Symptom when incorrectly adjusted	Poor S/N ratio or cross modulation.
Measuring instrument	---	1. Supply an RF signal(Programme). 2. Turn on AFT. 3. Adjust VR101 so that the picture and sound have no beat, noise and inter-modulation distortion. ВНИМАНИЕ!!!!Эта схема НЕ предназначена для продажи на дисках.Схему можно свободно получить на сайте "www.radiolom.by.ru"(www.hot.ee/juden001/).Если Вы её купили на болванке,то Вас капитально наебли!Не поддерживайте этих пидоров-торговцев краденным!!! WARNING!!!!This scheme not for selling on CD,its possible liberally get on put www.radiolom.by.ru.If You have sold this scheme on CD,that You have well defrauded.Do Not buy the thieved belongings!The Death thief!	
Test point	---		
EXT trigger	---		
Measurement range	---		
Input signal	RF signal (Programme)		
Input terminal	RF IN terminal		
PCB-MAIN (COMPONENT SIDE)			
VR101 FRONT			

ВНИМАНИЕ!!!Эта схема НЕ предназначена для продажи на дисках.Схему можно свободно получить на сайте

"www.radiolom.by.ru"(www.hot.ee/juden001/).Если Вы её купили на болванке,то Вас капитально наебли!Не поддерживайте этих пидоров-торговцев краденным!!!

WARNING!!!!This scheme not for selling on CD,its possible liberally get on put www.radiolom.by.ru.If You have sold this scheme on CD,that You have well defrauded.Do Not buy the thieved belongings!The Death thief!

[Power circuit] 4. B4 Voltage		Adjustment purpose	The best value of power supply voltage for horizontal deflection circuit.	
		Symptom when incorrectly adjusted	Too bright or too dark picture. Too compressed or too expanded horizontal width of picture.	
Measuring instrument	DC Voltmeter	1. Supply an RF signal (Programme). 2. Observe the voltage at TP9A and TP9B (Plus lead to TP9A). 3. Adjust VR951 so that the voltage is a value listed in the table below.		
Test point	+ lead : TP9A - lead : TP9B			
EXT trigger	---			
Measurement range	---			
Input signal	RF signal (Programme)			
Input terminal	RF IN terminal			

	21 inch	25 inch
Voltage Value	122 ± 3V	145 ± 1V

PCB-MAIN (COMPONENT SIDE)

VR951
TP9A
TP9B

FRONT

	21 inch	25 inch
Voltage Value	122 ± 3V	145 ± 1V


[CRT circuit] 5. Cut Off, White		Adjustment purpose Rate of electron beam shot from each electron gun of R, G and B. Symptom when incorrectly adjusted Too dark or too bright picture.
---	--	--

Measuring instrument	Oscilloscope
Test point	collector of Q651
EXT trigger	---
Measurement range	DIV 5V TIM 20μs
Input signal	---
Input terminal	---

- * This adjustment must follow the Purity and Convergence adjustments.
- * Preheat the set for twenty minutes or more.
- * Adjustment Item 12 (Sub Cont) must be performed immediately after this one.
- 1. Set the no signal condition in AV mode.
- 2. Set VR651, VR652 and VR653 to the mechanical centre position.
- 3. Set VR654, VR655 and VR201 to the mechanical centre position.
- 4. Observe the waveform at the collector of Q651. (Use GA connector pin ② for ground.)
- 5. Adjust VR651 so that the pedestal level is 150V.




PCB-MAIN (COMPONENT SIDE)



- 6. Observe the waveform at the collector of Q652. (Use GA connector pin ② for ground.)
- 7. Adjust VR652 so that the pedestal level is 150V.
- 8. Observe the waveform at the collector of Q653. (Use GA connector pin ② for ground.)
- 9. Adjust VR653 so that the pedestal level is 150V.

PCB-CRT (SOLDER SIDE)




- 10. Short - circuit the service terminals.
- 11. Adjust SCREEN control on F.B.T. to the point where one red, green or blue line becomes just visible.
- 12. Adjust two of VR651, VR652 and VR653 so that the horizontal line is white.
- 13. Open the service terminals.
- 14. Supply a video signal (White raster).
- 15. Adjust VR654 and VR 655 so that the entire screen is pure white.

6. Focus		Adjustment purpose Sharpness of picture. Symptom when incorrectly adjusted Poor sharpness of picture.
Measuring instrument	---	1. Supply an RF signal(Programme). 2. Adjust FOCUS volume on F.B.T. to the best overall focus. ВНИМАНИЕ!!!Эта схема НЕ предназначена для продажи на дисках.Схему можно свободно получить на сайте "www.radiolom.by.ru"(www.hot.ee/juden001/).Если Вы её купили на болванке,то Вас капитально наебли!Не поддерживайте этих пидоров-торговцев краденным!!! WARNING!!!This scheme not for selling on CD,its possible liberally get on put www.radiolom.by.ru.If You have sold this scheme on CD,that You have well defrauded.Do Not buy the thieved belongings!The Death thief!
Test point	---	
EXT trigger	---	
Measurement range	---	
Input signal	RF signal (Programme)	
Input terminal	RF IN terminal	
PCB-MAIN (COMPONENT SIDE)  F.B.T. (T551) FRONT		


7. Black Level		Adjustment purpose Black level of video signal. Symptom when incorrectly adjusted Too bright or too dark picture.
Measuring instrument	---	1. Supply a video signal (Colour bar). 2. Set COLOUR control to minimum. 3. Make sure that the blue bar area does not brighten. If necessary, adjust SCREEN control on FBT so that the blue bar area does not brighten. 4. Make sure that the red bar area is slightly bright. If necessary, adjust SCREEN control on FBT so that the red bar area is slightly bright.
Test point	---	
EXT trigger	---	
Measurement range	---	
Input signal	Video signal (Colour bar)	
Input terminal	VIDEO IN terminal	
PCB-MAIN (COMPONENT SIDE)  F.B.T. (T551)		

[Deflection circuit] . 8. Horizontal Centre		Adjustment purpose Horizontal position of picture.
		Symptom when incorrectly adjusted Picture too shifted to the left, or the right.

Measuring instrument	---	1. Supply a video signal (Monoscope). 2. Adjust VR531 so that readings of left and right markers are the same.
Test point	---	
EXT trigger	---	
Measurement range	---	
Input signal	Video signal (Monoscope)	
Input terminal	VIDEO IN terminal	




PCB-MAIN (COMPONENT SIDE)




9. East West PCC (25" model only)		Adjustment purpose Horizontal linearity of picture.
		Symptom when incorrectly adjusted Horizontal distortion of picture.


Measuring instrument	---	1. Supply a video signal (Crosshatch). 2. Press OPTIMUM button on the remote hand unit. 3. Observing the second line from both ends on the screen. Adjust VR5E1 so that the upper and lower distortions are symmetrical. 4. Adjust VR5E2 so that the both vertical lines are straight. Repeat step 3 to 4 above, if necessarily.
Test point	---	
EXT trigger	---	
Measurement range	---	
Input signal	Video signal (Crosshatch)	
Input terminal	VIDEO IN terminal	

PCB-PCC CONT (COMPONENT SIDE)









VR5E1



VR5E2

10. Horizontal Width (25" model only)		Adjustment purpose	Horizontal width of picture.
		Symptom when incorrectly adjusted	Too compressed or too expanded horizontal width of picture.
Measuring instrument	---	1. Supply a video signal (Monoscope). 2. Press OPTIMUM button on the remote hand unit. 3. Adjust VR5E3 so that the sum of left and right markers is 4.5 ~ 5.8 (equivalent to 7 ~ 9% overscan).	
Test point	---		
EXT trigger	---		
Measurement range	---		
Input signal	Video signal (Monoscope)		
Input terminal	VIDEO IN terminal		
PCB-PCC CONT (COMPONENT SIDE) 			

11. Vertical Height, Vertical Linearity, Vertical Centre		Adjustment purpose	Vertical and linearity of picture.
		Symptom when incorrectly adjusted	Too compressed or too expanded vertical height of picture. Vertical linearity of picture.
Measuring instrument	---	1. Supply a video signal (Monoscope). 2. Press OPTIMUM button on the remote hand unit. 3. Adjust VR452 for approx. 90% vertical size of raster. 4. Adjust VR451 for symmetry of vertical linearity. 5. Adjust VR452 so that the largest circle is a complete round. 6. Adjust S451 so that the largest circle is vertical centre position.	
Test point	---		
EXT trigger	---		
Measurement range	---		
Input signal	Video signal (Monoscope)		
Input terminal	VIDEO IN terminal		
PCB-MAIN (COMPONENT SIDE) 			

ВНИМАНИЕ!!!Эта схема НЕ предназначена для продажи на дисках.Схему можно свободно получить на сайте "www.radiolom.by.ru"(www.hot.ee/juden001/).Если Вы её купили на болванке,то Вас капитально наебли!Не поддерживайте этих пидоров-торговцев краденным!!!
WARNING!!!This scheme not for selling on CD,its possible liberally get on put www.radiolom.by.ru.If You have sold this scheme on CD,that You have well defrauded.Do Not buy the thieved belongings!The Death thief!



SERVICING PRECAUTION

SYMBOLS INDICATE COMPONENTS HAVING SPECIAL CHARACTERISTICS IMPORTANT TO SAFETY AND PERFORMANCE. THEREFORE REPLACEMENT OF ANY SAFETY PARTS SHOULD BE IDENTICAL IN VALUE AND CHARACTERISTICS. FOR ACCURACY OF THE REPLACEMENT REFER TO THE PARTS LIST OF SERVICE MANUAL.

DON'T DEGRADE THE SAFETY OF THE RECEIVERS THROUGH IMPROPER SERVICING.

• NOTE

1. DC voltages were measured from points indicated to the circuit ground with a high-Z voltmeter.
2. Waveforms were taken with standard colour bar signal.
3. TP6A, etc. show Test Points.

4. CAPACITORS

Value	Not indicated	PF, for numbers more than 1 μF, for numbers less than 1
Dielectric Strength	Not indicated :50V	
Tolerance	Not indicated =±10% No Tolerance is indicated for electrolytic capacitors and ±20% G=±2% P=+100% Q=+30% C=±0.25PF J=±5% -0% -10% D=±0.5PF K=±10% Z=+80% T=+200% F=±1PF M=±20% -20% -0% G=±2PF	
Sort	I except for chips	Not indicated : Ceramic capacitor (MP) : Polyester capacitor (PP) : Polypropylene film capacitor (ALM) : Aluminum electrolytic capacitor (TF) : Twin film capacitor (SC) : Semiconductor ceramic capacitor (MP) : Metalized paper (MPP) : Metalized plastic film capacitor (MMP) : Metalized polyester capacitor (MPP) : Polyester polypropylene film capacitor (PS) : Styrol capacitor (TAN or TANT) : Tantalum capacitor (E) : Electrolytic capacitor (BP or NP) : Non polarized electrolytic capacitor
	II Chips	Not indicated : Ceramic capacitor chip (E) : Electrolytic capacitor (BP or NP) : Non polarized electrolytic capacitor chip
Characteristic (only ceramic capacitor)	Not indicated : F or B (high dielectric percentage) CH,SL,etc. : Temperature compensating types	

5. Resistors

Value	Not indicated = Ω K = kΩ(1000Ω) M = MΩ(1000kΩ)
Wattage	Parts except for chips: Not indicated = 1/4W or 1/8W
	Chips: Not indicated = 1/10W
Tolerance	Not indicated =±5% D=±0.5% J=±5% F=±1% K=±10%
Short	Not indicated : Carbon resistor (S) : Fixed composition resistor (MB) : Metal oxide film resistor(type B) (CE) : Cemented resistor (W) : Wire wound resistor (M) : Metal film resistor (MPC) : Metal plate cement resistor (ML) : Metal liner resistor
	II Chip: Not indicated : Chip resistor

6. This is a basic schematic diagram. Some sets may be subject to modification according to engineering improvement.


SPECIFIC SYMBOL	
Zener Diode	Crystal unit
Varicap	Air Gap
Posistor	Part(resistor) attached on the copper-foil side of PCB
Thermistor	Ceramic filter
Fusible Resistor	

CT-21A5LST
 CT-21A5STX
 CT-25A5STX

1

ВНИМАНИЕ!!! Эта схема НЕ предназначена для продажи на дисках. Схему можно свободно получить на сайте "www.radiolom.by.ru" (www.hot.ee/jud en001/). Если Вы её купили на болванке, то Вас капитально наебли! Не поддерживайте этих пидоров-торговцев краденым!!! WARNING!!! This scheme not for selling on CD, its possible liberally get on put any radiolom by ru. If You

CT-21 A5LST CT-21 A5STX CT-25 A5STX




AL
ID
Y
D
E
F






**ВНИМАНИЕ!!!!Эта схема НЕ предназначена для продажи на дисках.Схему можно свободно получить на сайте "www.radiolom.by.ru"(www.hot.ee/juden001/).Если Вы её купили на болванке,то Вас капитально наебли!Не поддерживайте этих пидоров-торговцев краденным!!!
WARNING!!!!This scheme not for selling on CD,its possible liberally get on put www.radiolom.by.ru.If You have sold this scheme on CD,that You have well defrauded.Do Not buy the thieved belongings!The Death thief!**

CHASSIS BLOCK DIAGRAM



ВНИМАНИЕ!!!!Эта схема НЕ предназначена для продажи на дисках.Схему можно свободно получить на сайте "www.radiolom.by.ru"(www.hot.ee/ju den001/).Если Вы её купили на болванке,то Вас капитально наебли!Не поддерживайте этих пидоров-торговцев краденым!!! WARNING!!!!This scheme not for selling on CD,its possible liberally get on put www.radiolom.by.ru.If You have sold this scheme on CD,that You have well defrauded.Do Not buy the thieved belongings!The Death thief!



ВНИМАНИЕ!!!!Эта схема НЕ предназначена для продажи на дисках.Схему можно свободно получить на сайте "www.radiolom.by.ru"(www.hot.ee/juden001/).Если Вы её купили на болванке,то Вас капитально наебли!Не поддерживайте этих пидоров-торговцев краденным!!!
WARNING!!!!This scheme not for selling on CD,its possible liberally get on put www.radiolom.by.ru.If You have sold this scheme on CD,that You have well defrauded.Do Not buy the thieved belongings!The Death thief!

A



⑦0.7Vp-p(H)



①2.4Vp-p(H)



⑧0.5Vp-p(H)



②8.8Vp-p(V)

B




⑨1.3Vp-p(H)



③2.0Vp-p(H)



⑩0.9Vp-p(H)



④3.8Vp-p(H)

C



⑪5.5Vp-p(V)



⑤3.6Vp-p(H)




⑫12Vp-p(V)



⑥3.6Vp-p(H)

D




⑬0.7Vp-p(H)




⑭210Vp-p(H)

E






⑮95Vp-p(H)



⑯100Vp-p(H)

F







PCB-LED/PREAMP

COLOUR CODE TABLE FOR LEAD CONNECTOR

CODE	COLOUR	CIRCUIT
A	BLACK (Bk)	
B	BROWN (Br)	VIF
C	RED	VIDEO
D	ORANGE (O)	SOUND-AUDIO
E	YELLOW (Y)	VERT.
F	GREEN (Gr)	HORI.
G	BLUE (Bl)	CHROMA
H	VIOLET (V)	µ-COM
J	GRAY (Gy)	
K	WHITE (W)	POWER
L	PINK (P)	



PCB-CRT

IC101
TDA8361



IC702 X24C04P




ВНИМАНИЕ!!!Эта схема НЕ предназначена для продажи на дисках.Схему можно свободно получить на сайте "www.radiolom.by.ru"(www.hot.ee/jud en001/).Если Вы её купили на болванке,то Вас капитально наебли!Не поддерживайте этих пидоров-торговцев краденным!!!
WARNING!!!This scheme not for selling on CD,its possible liberally get on put www.radiolom.by.ru.If You have sold this scheme on CD,that You

IC601
TDA4661IC901
TEA2261


IC7701 HM6264ALSP

IC7703
AN5862K




ВНИМАНИЕ!!!Эта схема НЕ предназначена для продажи на дисках.Схему можно свободно получить на сайте "www.radiolom.by.ru"(www.hot.ee/juden001/).Если Вы её купили на болванке,то Вас капитально наебли!Не поддерживайте этих пидоров-торговцев краденым!!!

WARNING!!!This scheme not for selling on CD,its possible liberally get on put www.radiolom.by.ru.If You have sold this scheme on CD,that You have well defrauded.Do Not buy the thieved belongings!The Death thief!




EXT

USED FOR
CT-25ASSTX




COLOUR CODE TABLE FOR LEAD CONNECTOR


CODE	COLOR	CIRCUIT
A	BLACK (Bk.)	VIF
B	BROWN (Bn.)	VIDEO
C	RED (R)	SOUND, AUDIO
D	ORANGE (O)	VERT.
E	YELLOW (Y)	HORIZ.
F	GREEN (Gn.)	CHROMA
G	BLUE (Bl.)	A-COM
H	VIOLET (V)	POWER
J	GRAY (Gy)	
K	WHITE (W)	
L	PINK (P)	




IC601
TDA4661




IC901
TEA2261




IC7701 HM6264ALSP



IC7703
AN5862K



IC7702
SAA5246AP/E




IED — : NOT APPLIED

C554	C555	C556	C557	C558	C560	C568	J8	J23	J35	Q551	R458	R461	R462	R463	R464	R559	R671	R680	R681	R708	R954	R955	R962	VR451	VR951	Z551
0	4300	—	.43	—	1000u	—	0	0	0	2SD1554	47K	1.8	1.2K	1.2K	0	0	—	0	0	5.6K	120K	7.5K	—	—	B10K	—
—	9100	0	.82	0	3300u	0	—	—	—	2SD1555	15K	.82	820	820	330	—	0	—	—	10K	160K	8.2K	0	0	B20K	0

ВНИМАНИЕ!!! Эта схема НЕ предназначена для продажи на дисках. Схему можно свободно получить на сайте "www.radiolom.by.ru" (www.hot.ee/juden001/). Если Вы её купили на полванке, то Вас капитально наебли! Не поддерживайте этих пидоров-торговцев краденым!!!
WARNING!!!! This scheme not for selling on CD, its possible liberally get on put www.radiolom.by.ru. If You have sold this scheme on CD, that You have well defrauded. Do Not buy the thieved belongings! The Death thief!





T-21A5LST
T-21A5STX
T-25A5STX

3




ВНИМАНИЕ!!!Эта схема НЕ предназначена для продажи на дисках.Схему можно свободно получить на сайте www.radiolom.by.ru (www.hot.ee/juden001/).Если Вы её купили на болванке,то Вас капитально наебли!Не поддерживайте этих пидоров-торговцев краденным!!!

WARNING!!!!This scheme not for selling on CD,its possible liberally get on put www.radiolom.by.ru.If You have sold this scheme on CD,that You have well defrauded.Do Not buy the thieved belongings!The Death thief!



IC2J1
CXA1114P



CT-21A5LST
CT-21A5STX
CT-25A5STX

ВНИМАНИЕ!!!Эта схема НЕ предназначена для продажи на дисках.Схему можно свободно получить на сайте "www.radiolom.by.ru"(www.hot.ee/juden001/).Если Вы её купили на болванке,то Вас капитально наебли!Не поддерживайте этих пидоров-торговцев краденным!!!
WARNING!!!This scheme not for selling on CD,its possible liberally get on put www.radiolom.by.ru.If You have sold this scheme on CD,that You have well defrauded.Do Not buy the thieved belongings!The Death thief!