

**Note :** When changing the loading mechanism parts, apply the specified grease to the areas marked 'x x' as shown in the drawing.

The parts enclosed in the dotted boxes are supplied as an assembly. Therefore, they are not supplied separately except parts indicated with Ref. No.

Ref. No.	Part No.
①	SZZ0L30

