


5-3.



Note:

- Items with no part number and/or no description are not stocked because they are seldom required for routine service.
- All screws are Phillips (cross recess) type unless otherwise noted.
- (—) = slotted head
- (INT) shows the number of coils in spring.
- Circled letters (A) to (Z) are applicable to European models only.