


23 A BOARD

- TA, BV 3 x 8 7-685-646-71
• TA, BV 3 x 12 7-685-648-71



Remark

No.	Part No.	Description
101	4-363-677-00	PANEL, CONTROL
102	*1-611-014-00	H2 BOARD
103	1-507-657-00	JACK
104	Δ 1-554-966-11	SWITCH, PUSH (AC POWER)(1 KEY)
105	4-364-805-00	BUTTON, POWER
106	*4-342-117-00	CASE, SHIELD (MAIN), R
107	*1-606-794-00	N BOARD
108	*4-342-118-00	LID, SHIELD CASE, R
109	4-363-675-00	BUTTON, MULTI
110	*A-1340-571-A	D1 BOARD, COMPLETE
111	Δ 1-215-066-21	RES ASSY, HIGH-VOLTAGE

Remark

No.	Part No.	Description
112	*1-611-015-00	D2 BOARD
113	Δ 1-349-332-00	TRANSFORMER ASSY, FLYBACK
114	Δ 1-536-817-00	TERMINAL BOARD ASSY, ANTENNA
115	*A-1345-439-A	D BOARD, SUB, COMPLETE
116	*1-611-170-00	J1 BOARD
117	*1-611-013-00	H1 BOARD
118	4-361-939-00	PUSH BUTTON (B)
119	4-361-938-00	PUSH BUTTON (A)
120	*4-369-712-01	STOPPER
121	3-701-748-00	CLAMP
123	*4-368-658-01	INSULATOR (H)

Remark

Identified
Δ are
part

The components identified
by shading and mark Δ are
critical for safety.
Replace only with part
number specified.