Ref. No.	Part No.	Part Name & Description	Remarks
		MECHANISM PARTS	
101	RXF0045	FLYWHEEL(F) ASS'Y(DECK1)	
101	RXF0045	FLYWHEEL(F) ASS'Y(DECK2)	(P, PC)
101	RXF0040	FLYWHEEL(F) ASS'Y(DECK2)	(E, EB, EG, GC, GN)
102	RXF0046	FLYWHEEL(R) ASS'Y(DECK1)	
102	RXF0046	FLYWHEEL(R) ASS'Y(DECK2)	(P, PC)
102	RXF0047	FLYWHEEL(R) ASS'Y(DECK2)	(E, EB, EG, GC, GN)
103	RML0272	SWITCH LEVER	
104	RXQ0265	HEAD BASE ASS'Y	
104-1	RMB0266-1	SPRING, FOR./REV. SIDE ROD	
104-2	RXM0036	FOR./REV. SIDE ROD	
105	RGK0582-K	DRESSING PLATE	
106	RXQ0317	HEAD BLOCK(P.B.)(DECK1)	
106	RXQ0316	HEAD BLOCK(R/P)(DECK2)	
106-1	RHD17015	AZIMUTH ADJUSTMENT SCREW	
106-2	RMB0352	SPRING, HEAD HOLD	
106-3	RMQ0360A	CONNECTOR HOLDER	
107	RDV108ZA	BELT(DECK1)	
107	RDV108ZA	BELT(DECK2)	(P, PC)
107	RDV0015	BELT(DECK2)	(E, EB, EG, GC, GN)
108	RDK0019A	MAIN GEAR	
109	RMB0261	SPRING, HEAD BASE	
110	RMB0262	SPRING, BRAKE ROD	
111	RMB0263	SPRING(F)	
112	RMB0264	SPRING(R)	
113	RUW1472A	SPRING, TRIGGER LEVER	
114	RML0267A	TRIGGER LEVER	
115	RML0268A	FOR./REV. SIDE LEVER	
116	RMM0091A	BRAKE ROD	
117	RMS0398	MOVING IRON CORE	
118	RSJ0003	SOLENOID	
119	RUS609ZC	SPRING, TAPE PRESSURE	
120	RXG0036	REEL GEAR	
121	RXL0106	IDLER GEAR	
122	RXP0052	PINCH ROLLER(F) ASS'Y	
122-1	RMB0259	SPRING, PINCH ROLLER(F)	
123	RXP0053	PINCH ROLLER(R) ASS'Y	
123-1	RMB0260	SPRING, PINCH ROLLER(R)	
124	RDG0206-1	LOADING GEAR	
125	RDG0209A	INTERMEDIATE GEAR	
126	REM0036-1	CAPSTAN MOTOR	
127	REM0043	REEL MOTOR	
128	RHD26013	SCREW	
129	RMC0169	SHIELD PLATE	
130	RMQ0314A	SURASUTO SPACER	
131	RXG0037	FRICTION GEAR ASS'Y	
132	RYF0263-K	CASSETTE HOLDER ASS'Y	
132-1	RUS757ZA	SPRING, TAPE PRESSURE	
133	RMQ0430	RIVET	
134	RMB0269	SPRING, DRIVE LEVER	

Ref. No.	Part No.	Part Name & Description	Remarks
135	RML0270A-1	DRIVE LEVER	
136	RMQ0312A	DRIVE RACK	
137	RMB0268	SPRING, HOLDER HOOK	
138	RML0271A	HOLDER HOOK	
139	XTW2+6S	SCREW	
140	RXR0018	REEL TABLE	
141	XTW2+5L	SCREW	
142	XTW26+12S	SCREW	
143	XTW26+6L	SCREW	
144	RFKJSCH404AK	SUB CHASSIS ASS'Y	
145	RFKJSCH404BK	CHASSIS ASS'Y	