

Ref. No.	Part No.	Part Name & Description	Remarks
		TRANSFORMER(S)	
T601	RTP1K4B018-V	POWER TRANSFORMER	(E, EB, EG, GN) △
T601	RTP1K4C015-V	POWER TRANSFORMER	(P, PC) △
T601	RTP1K4E026-V	POWER TRANSFORMER	(GC) △
		OSC. (S) AND COMBINATION(S)	
Z701	RCDHC-278N	REMOTE SENSOR	
Z702	EF0EC6004T4	CERAMIC OSCILLATOR(6MHz)	
Z801	EXBF7L355SYV	COMBINATION PART(DECK1)	
Z802	EXBF7L355SYV	COMBINATION PART(DECK2)	
Z971A	EXBF6L306SYV	COMBINATION PART(DECK2)	
		DISPLAY TUBE(S)	
FL701	RSL0176-F	DISPLAY TUBE	
		SWITCH(ES)	
S601	SSR187-1	VOLTAGE SELECTOR	(GC) △
S701	EVQ21405R	DOLBY NR(B, C)	
S702	EVQ21405R	STOP(DECK2)	
S703	EVQ21405R	F. -SIDE PLAYBACK(DECK2)	
S704	EVQ21405R	R. -SIDE PLAYBACK(DECK2)	
S705	EVQ21405R	F. F. SEARCH(DECK2)	
S706	EVQ21405R	REW. SEARCH(DECK2)	
S707	EVQ21405R	OPEN/CLOSE(DECK2)	
S708	EVQ21405R	REC(DECK2)	
S709	EVQ21405R	PAUSE(DECK2)	
S710	EVQ21405R	AUTO REC MUTE(DECK2)	
S712	EVQ21405R	COUNTER2 RESET(DECK2)	
S714	EVQ21405R	POWER	
S715	EVQ21405R	STOP(DECK1)	
S716	EVQ21405R	F. -SIDE PLAYBACK(DECK1)	
S717	EVQ21405R	R. -SIDE PLAYBACK(DECK1)	
S718	EVQ21405R	F. F. SEARCH(DECK1)	
S719	EVQ21405R	REW. SEARCH(DECK1)	
S720	EVQ21405R	OPEN/CLOSE(DECK1)	
S722	EVQ21405R	REVERSE MODE	
S723	EVQ21405R	SYNCHRO START	
S724	EVQ21405R	SPEED(X1, X2)	
S725	EVQ21405R	COUNTER1 RESET(DECK1)	
S801	RSH1A024-U	OPEN DETECTION(DECK1)	
S802	RSH1A024-U	CLOSE DETECTION(DECK1)	
S803	RSH1A024-U	OPEN DETECTION(DECK2)	
S804	RSH1A024-U	CLOSE DETECTION(DECK2)	
S971	RSH1A018-U	MODE(DECK1)	
S971A	RSH1A018-U	MODE(DECK2)	
S972	RSH1A019-U	HALF(DECK1)	
S972A	RSH1A019-U	HALF(DECK2)	

Ref. No.	Part No.	Part Name & Description	Remarks
S973	RSH1A019-U	ATS(DECK1)	
S973A	RSH1A019-U	ATS(DECK2)	
S974A	RSH1A019-U	R. REC. INH. (DECK2)	
S975A	RSH1A019-U	F. REC. INH. (DECK2)	
S976A	RSH1A019-U	ATS(DECK2)	
		CONNECTOR(S) AND SOCKET(S)	
CN1A	RJS1A6214-1	CONNECTOR(14P)	
CN1B	RJS1A6714	CONNECTOR(14P)(DECK1)	
CN2A	RJS1A6214-1	CONNECTOR(14P)	
CN2B	RJS1A6714	CONNECTOR(14P)(DECK2)	
CN3A	RJS1A6227-1	CONNECTOR(27P)	
CN3B	RJS1A6827	CONNECTOR(27P)	
CN601	RJS1A1101T1	CONNECTOR(1P)	
CN602	RJS1A1101T1	CONNECTOR(1P)	(GC)
CN603	RJS1A1101T1	CONNECTOR(1P)	
CN604, 605	RJS1A1101T1	CONNECTOR(1P)	(GC)
CN606, 607	RJS1A1101T1	CONNECTOR(1P)	
CN609-611	RJS1A1101T1	CONNECTOR(1P)	
CN704	SJS50581BB	SOCKET(5P)	
CN801	RJT071H09A	CONNECTOR(9P)(DECK1)	
CN802	RJT071H11A	CONNECTOR(11P)(DECK2)	
CN803	RJR0113	MOTOR CONNECTOR(4P)(DECK1)	
CN804	RJR0113	MOTOR CONNECTOR(4P)(DECK2)	
CP1	SJTD313	CONNECTOR(3P)	
CP2	SJTD413	CONNECTOR(4P)	
CP801	RJS2A0205-2S	CONNECTOR(5P)(DECK1)	
CP802	RJS2A0205-2S	CONNECTOR(5P)(DECK2)	
CP803	RJP3G17ZA	CONNECTOR(3P)(DECK1)	
CP804	RJP4G17ZA	CONNECTOR(4P)(DECK2)	
CS971	RJU071H09M	SOCKET(9P)(DECK1)	
CS971A	RJU071H11M	SOCKET(11P)(DECK2)	
		JACK(S)	
JK1	SJF3069N	TERMINAL BOARD:REC/PLAY	
JK601	SJSD16	AC INLET	(P, PC, GN) △
JK601	SJS9236	AC INLET	(E, EB, EG, GC) △
JK602	RJS1A1602-1S	AC OUTLET	(P, PC) △
		GND PART(S)	
E1, 2	SNE1004-1	GND PLATE	
		FLAT CABLE(S)	
W701	REZ0640	FLAT CABLE(3P)	